

PILOT OPERATION.

Dock Side.

Check Power is applied to Unit.
Set Rudder and Trim Knob in Centre
Turn Unit on and adjust Knob to Mid Scale.
Wheel should either Pulse slowly or not move.
Turn Trim Clockwise - Wheel should turn Clockwise and move
Rudder in direction to turn to Starboard.
Turn Trim Anticlockwise - Wheel should Turn Anticlockwise and move
Rudder in direction to turn to Port.
Turn Trim to Centre and Wheel should move Wheel back to Centre.
Turn Unit Off.

AT SEA.

Set Rudder and Trim at Mid Scale.
Steer to desired Course.
Turn Unit on and Set Sheer to Mid Scale.
Adjust Trim for desired Course.
Adjust Rudder for amount of Rudder applied. i.e. over Steering or
under Steering.
Adjust ~~Sheer~~ **Sensitivity** for accurate Course holding.

TO CHANGE COURSE.

Turn Unit off.
Steer to New Course, Turn Unit on and return Knob to original position.
OR Push Button and vessel will turn to
new course Release Button when vessel is on
new course.